R

DIVIARK

INTRODUCTION

WHAT IS ID-MARK?

ID-MARK is an imaging system for making identification and recognition products, either on aluminum or polyester sheets, in a variety of colors and sizes. It is a simple system that anyone can use.

HOW DOES ID-MARK WORK?

ID-MARK sheets are processed with UV light and water. Areas of the plate exposed to UV light harden and will remain on the plate after processing. Unexposed areas will wash away with water.

WHAT DO I NEED TO GET STARTED WITH ID-MARK?

- Artwork or Film (Negative or Positive)
- UV Exposure Unit
- ID-MARK sheets
- Water
- Cotton Pads
- · Heat Gun or Hair Dryer



ID-MARK PROCESSING

HOW DO I EXPOSE THE ID-MARK SHEET?

- Place film on top of the colored side of the ID-MARK sheet.
- Expose plate to UV light.
 Length of exposure will depend upon exposure unit and material used. (see chart)

EXPOSURE DEVICE

MATERIAL	Exposure Unit #8796	Exposure Unit #8797	NuArc 26-1KS #7950
Aluminum Sheets	4 Minutes	5 Minutes	100 Light Units
White and Yellow Polyester Sheets	4 Minutes	5 Minutes	100 Light Units
Clear Polyester Sheets	3 Minutes	4 Minutes	70 Light Units
Reflective Sheets	3 Minutes	4 Minutes	70 Light Units
Photoluminescent Sheets	3 Minutes	4 Minutes	70 Light Units

- For other units, we suggest exposing test strips before processing full sheets.
- We recommend a 25 watt Black Light bulb with a UV nanometer range of 350-400.

HOW DO I DEVELOP THE ID-MARK SHEET?

 Hold the exposed sheet under a stream of cold water. Unexposed resist will wash away.





- Use a wet cotton pad to aid in removing excess resist by <u>rubbing gently</u>.
- Give sheet final rinse after rubbing with pad.

HINTS:

- Use light pressure when removing resist.
- Make certain cotton pad is wet when wiping sheet.
- Continue to wipe until all excess resist is gone.

ALTERNATIVE METHOD:

- Place exposed sheet in plastic tray and spray with cold water from spray bottle until the sheet is completely wet.
- Use a wet cotton pad and <u>rub gently</u> to remove resist.

ARTWORK PREPARATION

WHAT DO I USE FOR FILM?

- Output from printers including:
 - -Vellum
 - -Overhead transparencies for laser or inkjet printers
- Commercial photographic film
- ID-MARK reversing film



- Clip Art Books
 - Pictures
 - Drawings
- Computers Clipart

HOW DO I MAKE THE FILM?

- Commercial Photographic Equipment or Film Service Bureaus
- Print your artwork, from a computer, onto an overhead transparency or vellum using a laser or inkjet printer. Print an "emulsion-side down" (or mirrored) image. Printing emulsion-side down provides for the best quality reproduction of your artwork. Always print with darkest print setting.

For example,

in CorelDraw, select "Emulsion-Side-Down" (V.7), or "Mirror" (V.8) in print settings.





 Dry with a heat gun or hair dryer to ensure even drying.

<u>Dó not</u> let sheet air dry.



FINISHING AND FABRICATING

ARE THERE ADDITIONAL FINISHING STEPS I CAN USE ON MY ID-MARK SHEET?

- Finished ID-MARK sheets can be cut/trimmed with scissors, paper cutters, trimmers or shears.
- If you see fingermarks, water spots, etc. on your dried sheet, you may use a cleaning solvent such as the ID-MARK Cleaner. After cleaning, remember to dry the sheet.

 If you need to apply extra protection to your ID-MARK sheet, you can apply ID-MARK protective overlam material. (Complete instructions in package.)

 If you want a different background color on your aluminum sheet, you can apply one of our background coloring dyes. (Complete instructions in package.)



When conditions such as abrasion, outdoor use and exposure to harsh environments occur, ID-MARK overlams are recommended to add additional protection. All overlam films can be applied by hand and no special equipment is required. Choose from the following overlam films:

UV Gloss Overlam - recommended if finished sheet will hang in direct sunlight. The finish of UV Gloss

Overlam is shiny.

Matte Overlam -

for applications that require a flat, non-reflective surface appearance. Protects from moisture and abrasion.

Velvet Polycarbonate Overlam - produces a "frosty" look. Provides excellent abrasion resistance as well as moisture resistance.

For Technical Support Please Call 1-800-635-6154 PROCESSING TIPS & HINTS

PROBLEM: Part or all of the image is lost during rinsing.

Sheet is under-exposed, resist not Cause:

hardened enough.

Solution: Exposure time needs to be increased.

Cause: Too much pressure exerted when wiping and

rinsing off resist.

Solution: Use only light pressure. Let the cotton pad and

water do the work.

Poor contact between film and ID-MARK sheet Cause:

during exposure.

Solution: Contact must be extremely close between ID-MARK

material and film during exposure.

Not enough contrast between clear and opaque Cause:

areas on film.

Solution: Artwork images must be opaque, but the

actual film needs to be clear.

Cause: Wrong type of exposure device.

Solution: Light source must be ultra-violet (black light).

Incandescent light sources (such as office

copiers) will not work.

Cause: Photosensitive side on the ID-MARK material is

facing away from the light during exposure.

Solution: The photosensitive side (colored side) needs

to face the light during exposure.

Cause: Emulsion side on the film is not in contact with

the photosensitive side on the ID-MARK material.

Solution: Use film with emulsion or toner on the film

in contact with the photosensitive (colored) side

on the ID-MARK material.

Leaving water on the sheet too long. Cause:

Solution: ID-MARK will process without a great deal of water.

Soaking the sheet with too much water will cause

all the resist to soften and wash away.

PROBLEM: Double or fuzzy images appear during processing.

Film (artwork) shifted during exposure. Cause:

Solution: This can happen if the film and the ID-MARK

material are not held in extremely close

contact during exposure.

Film was printed with emulsion side up. Cause:

Resulting light diffusion caused shadows or

double images.

Solution: Film needs to be printed so that it is right-reading

with the emulsion or toner side in contact with

photosensitive side of sheet.

PROBLEM:

Pinholes or voids appear on correctly exposed **ID-MARK material.**

Cause: Dirt or lint on cover

glass of exposure

device.

Solution: Clean glass.

Cause: Dirt or lint on film.

Solution: Clean off film with lint free cloth.

PROBLEM: No image appears at all.

Cause: Sheet is overexposed.

Solution: Reduce exposure time. Ensure opaque (black)

areas on film are dark enough to hold

back light.

Cause: Art (film) images are not opaque enough to

block the light during exposure.

Solution: Film must be transparent, but the artwork

images must be opaque.

Cause: Material exposed before use.

Solution: Store unexposed material in sealed black pouch

when not in use.

PROBLEM: Scratches on correctly exposed

ID-MARK material.

Too abrasive a pad used in rinsing and Cause:

wiping off resist.

Solution: A soft, lint-free cotton pad, such as an

AppliPad (Part # 7020) should be used in rinsing and wiping off the emulsion. Do not use paper towels or facial tissues.

Cause: Fingernails or rings make contact with resist

when wet.

Solution: Make certain that only the cotton pad comes in

contact with the ID-MARK material while it is wet.

For Technical Support Please Call 1-800-635-6154



ID-MARK is a trademark of Horizons Incorporated